

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
262724	3	ADAPTER, HAND LAP BUSHING	D
290169	1	TEE ASSY RESTRICTOR	
2024212-1	2	FIXTURE, PIN REMOVAL	
2024222-1	2	TEST FITTING	-
2024244-1	1	PLATE, BEARING REMOVAL	A
2024244-2	1	PLATE, BEARING REMOVAL	A
2024244-3	1	PLATE, BEARING REMOVAL	A
2024244-4	1	PLATE, BEARING REMOVAL	A
2024282-8	2	STRETCH SHAFT	F
2024354-1	2	FIXTURE, TORQUE, NUT	-
2024380-1	4	MICING CAP	
2024447-1	4	MEASUREMENT BRIDGE	-
2024448-1	2	FIXTURE, TRANSFER	
2024495-1	2	FIXTURE, NOZZLE PRESS	-
2024564-1	2	BALANCE ARBOR	-
2024572-1	1	PLUG SET, PRESSURE TEST (PARTIAL)	A
2024606-1	1	FIXTURE, ALIGNMENT	
2024627-1	2	BEARING DRIVER	-
2024634-1	2	ALIGNMENT TOOL, PILOT	
2024684-1	1	FIXTURE, END PLAY	
2024839-1	1	PRESS TOOL	-
2024927-1	1	TEST END CAP	-
2025020-2	2	SHAFT STRECH	
2025020-3	1	ADAPTER, HOUSING	A
2025020-4	1	WRENCH	A
2025027-3	1	BAR	-
2025028-1	4	ADAPTER, TORQUE, TANGED (S/S BY 2025579)	
2025183-1	3	PICK UP SPEED	-
2025229-1	1	EXHAUST COVER	A
2025300-1	2	CAP	-
2025310-1	1	SHAFT, ALIGNMENT	
2025548-1	1	KIT, ALIGNMENT	
2025559-1	1	SHAFT TURBINE MODULE	A
2025579-1	3	TORQUE ADAPTER	-
2025582-1	2	TORQUE FIXTURE	-
253562-2	1	SPANNER WRENCH	C
253722-1	1	PULLER ASSY.	
255664-1	1	EXPANSION ROD	
256071	3	ADAPTER, DRILL MOTOR	A
256377-5	0	BEARING, HALF, BALANCE	G
256377-6	1	BEARING, HALF, BALANCE SUPP, ROT. ASSY	
256377-9	1	BEARING, HALF, BALANCE	G
268228	1	HOLDER ASSY.	
278303-1	1	BALANCING SUPPORT	
280219-1	1	WRENCH, SOCKET, INTERNAL	F
280377-1	1	SPANNER WRENCH	D
281423-1	2	CABLE ASSY, SPECIAL PURPOSE	K
281688-4-	1	SPUR GEAR WRENCH	
281728-1	1	SEAL DRIVER	B
281742-3	1	PULLER ASS'Y CARBON SEAL	-
282401-1	4	PROBE	
283292-1	1	GASKET	A

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
283973-1	1	BRACKET ANTI-RO	B
284045-1-1	2	PULLER	C
284168-11	1	PULLER BEARING	F
284193-1-1	1	DRILL JIG SHAFT	B
284197-1-1	1	RETAINER ROLLER	A
284275-1-1	1	SHAFT, INSTALLING PILOT	E
284491-1-1	1	BALANCE ARBOR - Check with customer regarding the engine	
284520-4-1	1	DUCT ASSY, SENSOR	E
284670-1-1	2	ADAPTER ASSY TORQUE WRENCH	B
284681-1	1	COLLET	
284846-1	3	HOLDER TUBAN WHEEL	
285159-1-1	1	WRENCH SET, NUT TORQUE	D
285167-17	1	ROTATING SPACER GROUP	A
285167-19	2	ROTATING SPACER GROUP	A
285171-1-1	3	HOLDER ASSY, VALVE LEAKAGE TEST	A
285418-1	1	ADAPTER, TORQUE	B
285640-1-1	1	HOLDER, RING INSTALLING (CHECK REV E-NOW J)	
285748-1-1	2	PUNCH, CENTER AUTOMATIC	A
285776-1-1	1	BEARING & BUSHING DRIVER	C
285793-1-1	2	DRIVER, SEAL	-
285802-1-1	1	HOLDER & ADAPTER	B
285822-1-1	2	INSERT, BALANCE SUPPORT	
285845-2-1	1	SUPERCEDED BY 831168-1	
285948-1-1	1	SEAL, INSTALLING PILOT	-
286021-1	3	TUBE ASSY, METAL	
286022-1	6	BORESCOPE GUIDE TUBE	B
286023-1	5	BORESCOPE GUIDE TUBE	B
287045-1	2	ADAPTER, TORQUE WRENCH, INTERNAL SPLINE	
287220-1-1	1	SIMULATOR ASSY, UNFEATHERING	A
287277-1	3	ADAPTER, TORQUE WRENCH	A
287410-1	2	PULLER ASSY, MECH	A
287416-1-1	2	HOLDER & ADAPTER, TORQUE	C
287463-10	4	GAGE, DEPTH, FIXED	J
287463-11	5	GAGE, DEPTH, FIXED	J
287463-12	5	GAGE, DEPTH, FIXED	J
287463-13	2	GAGE, DEPTH, FIXED	J
287463-14	4	GAGE, DEPTH, FIXED	J
287463-15	2	GAGE, DEPTH, FIXED	J
287463-16	4	GAGE, DEPTH, FIXED	J
287463-17	4	GAGE, DEPTH, FIXED	J
287463-18	4	GAGE, DEPTH, FIXED	J
287463-19	5	GAGE, DEPTH, FIXED	J
287463-3	4	GAGE, DEPTH, FIXED	J
287463-4	5	GAGE, DEPTH, FIXED	J
287463-7	4	GAGE, DEPTH, FIXED	J
287463-8	3	GAGE, DEPTH, FIXED	J
287514-15	1 set	TUBE	A
287518-1	1	FIXTURE, RUNOUT CHECKING	H
287539-10	8	RESTRICTOR, FLUID FLOW	K
287539-11	12	RESTRICTOR, FLUID FLOW	K
287539-12	12	RESTRICTOR, FLUID FLOW	K
287539-13	12	RESTRICTOR, FLUID FLOW	K

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
287539-14	14	RESTRICTOR, FLUID FLOW	K
287539-15	35	RESTRICTOR, FLUID FLOW	K
287539-16	43	RESTRICTOR, FLUID FLOW	K
287539-17	10	RESTRICTOR, FLUID FLOW	K
287539-18	10	RESTRICTOR, FLUID FLOW	K
287539-19	13	RESTRICTOR, FLUID FLOW	K
287539-2	28	RESTRICTOR, FLUID FLOW	K
287539-20	9	RESTRICTOR, FLUID FLOW	K
287539-21		RESTRICTOR, FLUID FLOW	K
287539-22	8	RESTRICTOR, FLUID FLOW	K
287539-23	13	RESTRICTOR, FLUID FLOW	M
287539-24	8	RESTRICTOR, FLUID FLOW	K
287539-25	10	RESTRICTOR, FLUID FLOW	K
287539-3	27	RESTRICTOR, FLUID FLOW	K
287539-31	2	RESTRICTOR, FLUID FLOW	M
287539-37	10	RESTRICTOR, FLUID FLOW	K
287539-38	10	RESTRICTOR, FLUID FLOW	K
287539-39	8	RESTRICTOR, FLUID FLOW	M
287539-4	41	RESTRICTOR, FLUID FLOW	K
287539-40	10	RESTRICTOR, FLUID FLOW	K
287539-6	20	RESTRICTOR, FLUID FLOW	M
287539-7	16	RESTRICTOR, FLUID FLOW	K
287539-8	14	RESTRICTOR, FLUID FLOW	K
287539-9	10	RESTRICTOR, FLUID FLOW	K
287813-1	1	PULLER	-
287891-1	2	GUIDE, INSTALLATION, HOUSING	A
288071-1	2	BRACKET ASSY, TESTER	F
288277-1	1	COVER ASSY., FILTER PLUG	A
288468-1	4	ADAPTER FUEL NOZZLE	-
289209-1	3	ADAPTER, TORQUEWRENCH	
289253-1	1	ADAPTER, HAND LAP	A
289253-2	1	ADAPTER, HAND LAP	A
289492-1-1	1	ADAPTER SET, INSTALLATION	A
289555-1	1	SEAL DRIVER	A
289579-1	1	GAGE, BUTTERFLY ANGLE	C
289639-2	1	HOLDER, WRENCH, SHAFT ASSY.	E
289756-1	2	DRIVER, SEAL, INSTALLATION & REMOVAL	-
289756-2	1	DRIVER, SEAL, INSTALLATION & REMOVAL	-
289764-1	1 set	ADAPTER SET, MAINT STAND (Needs BO)	
289766-1	4	WRENCH, SHAFT HOLDING	B
289769-17	3	ROD	
289769-19	3	ROD END ASY	
289770-1	1	SUPERCEDED BY 289770-2	
289770-2	1	PULLER, MECH TUBE	G
289773-1	3	ADAPTER, HOISTING LP TURBINE	-
289776-1	1	Holding & Indexing Fixture Assy	
289778-1	4	DRIVER ASSY, MECH. SEAL REMOVAL	-
289788-1	2	CLAMP, IMPELLER & ROTOR	B
289789-1	1	ADAPTER, HOIST	A
289789-1	5	HP TURBINE HOISTING ADAPTER	A
289790-1	2	DRIVER, SEAL INSTALLATION & REMOVAL	B
289791-19	1	WRENCH ASSY, FIXTURE, SHAFT	M

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
289791-2	1	FIXTURE ASSY, SHAFT STRETCH, HP	
289792-8	3	HOLDER, HP SHAFT	
289794-4	1	PULLER ASSY., MECHANICAL, BEARING REM.	J
289798-1	2	DRIVER BEARING	-
289799-1	4	DRIVER BEARING	A
289801-1	5	DRIVER, SEAL INSTALLATION & REMOVAL	B
289801-2	6	DRIVER, SEAL INSTALLATION & REMOVAL	B
289802-1	12	PILOT, SEAL INSTALLING	-
289802-2	16	PILOT, SEAL INSTALLING	-
289802-3	6	PILOT, SEAL INSTALLING	-
289803-1	6	DRIVER BEARING	-
289804-1	6	DRIVER BEARING	-
289806-1	1	DRIVER, INSTALLATION, BEARING	-
289808-1	2	PULLER SET, SEAL REMOVAL	B
289813-1	1	HOLDER, ATOMIZER	B
289816-2	3	HOLDER, GEARSHAFT	B
289819-1	1	LOAD SIMULATOR SHAFT LOCKING	-
289820-2	1	LOAD SIMULATOR, BACKLASH CHECKING	
289826-1	1	ADAPTER ASS'Y, HYDROLIC LOAD (NEEDS CA)	-
289834-1	1	PULLER, BEARING INSTALL	B
289837-2	1	PULER ASSY, MECHANICAL, REMOVE, BEARING	
289848-1	2	ADAPTER ASSY, BRAKE RELEASE	C
289895-1	2	ADAPTER, FITTING TEST	-
289903-1	3	PULLER & ADAPTER ASSY BIG REM	-
289906-1	1	HOLDER FAN SHAFT	B
289910-1	1	CRADLE, BALANCING FAN SHAFT	A
289921-1	1	FIXTURE ASS'Y (NEEDS ASSEMBLY)	E
289922-1	2	FIXTURE, LOCKPLATE REMOVAL	-
289926-2	1	FIXTURE ASSY, RIVET	H
289935-11	1	ARBOR	
289935-13	1	ARBOR	
289951-1	6	GAGE ASSY, GEAR POSITIONING	A
290097-4	10	THERMOCOUPLE ASSY	J
290166	5	ADAPTER ASSY	H
290167	4	ADAPTER ASSY	J
290221-1	2	ADAPTER ASSY, VALVE TEST SET	
290222-1	4	ADAPTER ASSY VALVE TEST SET	D
290224-1	1	ADAPTER ASSY VALVE TEST SET	E
290235-4	2	FITTING ASSY, TEST	R
290237-1	1	FITTING ASSY, TEST	J
290237-1	2	FITTING ASSY, TEST	J
290239-1	15	FITTING ASSY, TEST	M
290290-1	5	FITTING ASSY, TEST	F
290312-1-1	8	FITTING ASSY, TEST PORT	B
290314-1	18	FITTING ASSY, TEST PORT	F
290489-1	1	ADJUSTING NUT, SHAFT STRETCHING	F
290489-2	1	ADJUSTING NUT, SHAFT STRETCHING	F
290564-1	1	SUPPORT, BALANCE	B
290566-12	1	ARBOR, TIE BOLT	M
290566-15	2	ARBOR, TIE BOLT	M
290566-17	1	ARBOR, TIE BOLT	M
290566-19	5	ARBOR, TIE BOLT	M

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

8/4/2010

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

PART NUMBER	QTY	DESCRIPTION	REV
290566-20	2	ARBOR, TIE BOLT	M
290566-2	3	ARBOR TIE BOLT (need #)	M
290566-21	2	ARBOR, TIE BOLT	M
290566-25	2	ARBOR, TIE BOLT	M
290566-27	2	ARBOR, TIE BOLT	M
290566-3	1	ARBOR, TIE BOLT	M
290566-32	2	ARBOR, TIE BOLT	M
290566-33	1	ARBOR, TIE BOLT	M
290566-4	2	ARBOR, TIE BOLT	M
290566-6	5	ARBOR, TIE BOLT	M
290707-2	1	ADAPTER	A
290947-1	2	SHAFT, STRETCH	K
291055-1	7	ANVIL, RIVET, TURBINE WHEEL	A
291115-1	1	BEARING LAPPING TOOL	-
291144-1	1	HOLDER ANTI ICE SEAL SUPPORT	-
291144-1	2	HOLDER ANTI ICE SEAL SUPPORT (Russ')	-
291266-1	1	GAGE	-
291277-1	1	TEST FIXTURE, VALVE TEST	-
291280-1	1	PULLER ASSY, MECH, SEAL RETAINER	D
291357-2	3	TOOL, POSITIONING, BUTTERFLY	-
291396-23	2	ADAPTER, STEP PLATE	N
291397-15	2	ADAPTER ASSY, SPLIT PLATE	N
291474-1	1	SEAL PILOT	A
291572-1	1	CABLE ASSY, SPECIAL PURPOSE	I
291581-1	1	ADAPTER HOLDER VALVE TEST	-
291629-2	1	DUMMY BEARING	A
291629-3	1	SIMULATOR, BEARING	-
291629-4	1	SIMULATOR, BEARING	-
291678-1	2	ADAPTER, PNEUMATIC TEST, FUEL MANIFOLD	-
291679-1	2	ADAPTER, PNEUMATIC TEST, FUEL MANIFOLD	-
291738-1	1	GAGE, CONNECTOR POSITIONER	-
291790-1	1	PLUG, OIL TUBE	A
291811-2	1	TESTER ASSY, ELECTRICAL	F
291816-1	2	SLEEVE, ALIGNMENT	-
291892-1	7	FLARING TOOL RIVET	E
291892-4	4	FLARING TOOL	E
291892-5	6	FLARING TOOL	E
291899-1	2	GUIDE SET	-
291900-31	3	LUG, NUT	K
291921-1	1	PLATE SET, ADAPTER KIT	-
291926-1	1	FIXTURE, SHAFT ALIGNMENT	A
291928-1	3	PULLER, MECHANICAL TURBING BRG SUPPOF	B
291964-5	1	PUSHER, SEAL INSTALLATION/REMOVAL	B
291967-1	1	ADAPTER, PULLER	E
291967-2	2	ADAPTER, PULLER	E
291967-4	2	ADAPTER, PULLER	E
291967-5	1	ADAPTER, PULLER	E
291967-6	2	ADAPTER, PULLER	E
291967-7	2	ADAPTER, PULLER	E
291967-8	2	ADAPTER, PULLER	E
291968-1	1	DRIVER, INSTALLER, SEAL	A
291969-1	1	PLATE, REMOVAL, BEARING	-

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
291984-1	2	PULLER SCROLL HOUSING	C
292033-2	1	SHAFT, STRETCH	J
292089-2	2	ARM, EXTENSION	C
292101-1	8	REGULATOR, PRESSURE	F
292356-1	2	BRASS NUT, SLOTTED	-
292374-1	1	SHAFT, STRETCH	J
292471-1	1	GAGE ASSY	
292472-1	2	GAGE ASSY	
292473-1	4	TUBE ASSY	
292523-1	7	PLUG ASSY.	
292976-1	1	COUPLING, HALF ADAPTER	B
293073-1	1	PULLER, MECH. COMP STATOR	A
293078-1	2	ADAPTER HOIST	-
293167-1	2	SPACER, SHIM CLEARANCE	-
293168-1	1	SUPPORT BLOCK INLET HSG	A
293181-1	2	FIXTURE ASSY, RIVET	-
293195-1	3	ADAPTER PLATE, FIBEROPTIC	
293252-1	1	ADAPTER ASSY, HANDLE	C
293301-1	5	EXTRACTOR, TRANSFER TUBE	-
293317-1	4 sets	MANIFOLD SET HOLDER	G
293328-1	1	SWAGE, MECHANICAL, SELF-LOCK NUT	
293330-1	2	PULLER, MECH CARRIER	
293341-1	1	PULLER MECH FAN CORE	A
293361-1	1	GUIDE, FAN TURBINE SHAFT	B
293363-1	2	DRIVER, INSTALLATION & REMOVAL, SEAL	-
293363-2	1	DRIVER, INSTALLATION & REMOVAL, SEAL	-
293369-19	2	JAW, INSERT	J
293379-21	2	BALL LOCK PIN ASSY	
293399-1	1	FIXTURE ASSY, HYDRAULIC	F
293415-1	1	SUPPORT & DRIVER, INSTALLATION	-
293419-1	1	ADAPTER ASSY, HOIST	E
293419-13	2	Part of 293419-1	
293430-1	2	PILOT COMPRESSOR ROTOR	A
293441-1	1	GAGE SHIM CHECKING	A
293495-1	2	PULLER ASSY. MECH. SEAL	C
293665-2	3	HOLDER PLANET ASSEMBLY	A
293727-1	1	FIXTURE, RUNOUT HP SHAFT	F
293735-1	7	WASHER	
293814-1	1	SHIM CHECKING DUMMY BRG SET	A
293814-2	1	SHIM CHECKING DUMMY BRG SET	A
294153-1	2	ADAPTER, PRESSURE CHECK	
294175-1	1	ROLLER SET, FLANGE FORM	
294202-1	1	ADAPTER KIT	
294207-1	1	HOLDING FIXTURE FUEL NOZZLE	-
294240-2	2	HAND LAPPING TOOL	B
294240-3	1	ADAPTER, HAND LAP	B
294341-1	1	PULLER ASSY, MECHANICAL	B
294345-1	1	ADAPTER, T-HANDLE	-
294347-1	1	ADAPTER, T-HANDLE	-
294364-1	1	DRIVER, INSTALLATION, SEAL	-
294365-1	1	PULLER ASSY, MECH, LIP SEAL	C
294381-1	4	DIAPHRAGM ASSY	-

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

8/4/2010

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

PART NUMBER	QTY	DESCRIPTION	REV
294401-2	1	PULLER ASSY, MECH	A
294406-1	1	PULLER ASSY, MECH	C
294419-2	1	FIXTURE ASSY, HYDRAULIC	G
294422-1	1	FIXTURE ASSY, SHAFT STRETCH (No Pump Ass)	H
294426-1	1	SUPPORT & ADAPTER SET, HP SHAFT	-
294429-1	1	ADAPTER ASSY, HOIST, ENGINE CORE	A
294441-1	1	BASE PRESS	-
294506-1	4	INDICATOR, BACKLASH	
294512-1	1	ADAPTER, FILTER TEST	
294571-23	1	PULLER ASSY, IMPACT TYPE - Needs P.I.	B
294612-1	1	BAR PRY COMBUSTOR INNER SKIRT	B
294625-1	1	DECRIMPER, MECH, HP TURB NUT (Need Assy)	
294661-1	1	ADAPTER, TORQUE NUT	
294670-1	1	WRENCH SET	C
294681-1	1	STAKING PUNCH	A
294760-1	2	ADAPTER, SPLINED, TORQUE MULTI	A
294838-1	1	GUIDE #6 BEARING	-
294839-2	1	GAGE ASSY, SHAFT STRETCH	D
294869-1	2	PLATE, REMOVAL, BEARING	-
294912-1	2	ADAPTER, PULLER FAN ASSY	B
294937-1	1	PLUG, INBOARD CASCADE	A
294938-1	1	DEFLECTOR ENGINE EXHAUST	G
294945-1	1	GAGE, BLADE EROSION	A
294977-203	1	SHAFT	
295194-1	2	NUT, SHAFT STRETCHING	G
295194-5	3	NUT, SHAFT STRETCH	G
295194-6	5	NUT, SHAFT STRETCH	G
295229-1	1	PUNCH, CRIMP, CUP WASHER	B
295230-1	1	PUNCH, DECRIMP	B
295342-1	0	STRETCH SHAFT	A
295421-1	4	LPC STRETCH SHAFT	E
295539-1	1	Part of 293419-1	
295540-1-	1	Part of 293419-1	
295784-2	1	SHAFT, STRETCH	
295834-1	1	MARKER, IDENTIFICATION	D
295835-2	1	CABLE ASSY	
295840-1	2	CABLE ASSY	
295978-1	1	CABLE ASSY.	
296012-1	1	GUIDE ALIGNMENT, OIL TUBE	-
296097-1	1	PRY BAR DESWIRL	-
296126-1	1	GUIDE, INSTALLATION, SEAL	C
296133-1	4	DUMMY NUT COMPRESSOR	-
296136-1	1	DRIVER, REMOVAL, GEARSHAFT	-
296153-1	1	MOUNT	-
296199-1	1	TRANSMITTER ASSY, POWER LEVER	E
296232-1	1	ADAPTER ASSY, ALIGNMENT	B
296272-2	2	RESTRICTOR, FLUID FLOW	
296384-1	1	GUIDE, INSTALLATION, SEAL	J
296385-1	1	SEAL PRESSING DRIVER	D
296385-1	1	SEAL PRESSING DRIVER	D
296385-2	1	SEAL PRESSING DRIVER	D
296402-2	1	TIE ROD, DUMMY	B

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

8/4/2010

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

PART NUMBER	QTY	DESCRIPTION	REV
296451-1	1	PLATE SEAL REMOVAL	A
296488-1	1	GAGE, SHIM CHECKING	-
296497-1	3	TOOL SET CRIMPER	-
296509-1	1	INSTALLER, PRESSURE	E
296512-1	3	PULLER RETAINER SEAL (2 pcs need P.I.)	B
296513-1	2	PILOT, SEAL INSTALLING	B
296515-1	1	ADAPTER, HALF RING	A
296517-1	1	ADAPTER ASSY, LOCKUP	A
296562-1	1	PULLER ASSY, MECH, INST, BEARING	K
296564-1	1	ADAPTER, HOISTING, TURBO PROP	G
296564-2	1	ADAPTER, HOISTING, TURBO PROP	G
296564-3	1	ADAPTER, HOISTING, TURBO PROP	G
296581-1	7	ADAPTER ASSY, TORQUE WRENCH	A
296582-1	1	ADAPTER ASSY, ANTI-ROTATE	-
296594-1	1	ADAPTER SET, TORQUE WRENCH	D
296597-1	1	DRIVER & SUPPORT ASSY, INST/REM	A
296607-1	1	FIXTURE ASSY, INST / REM LOCKPLATE	-
296609-1	3	ADAPTER, METERED PRESSURE TEST	
296609-2	3	ADAPTER, METERED PRESSURE TEST	
296611-1	2	ADAPTER, PUMP TEST	
296633-1	1	SUPPORT & DRIVER, ALIGNMENT	-
296645-1	1	SPECIAL WRENCH	
296646-1	1	HOLDER & DRIVER, CARBON SEAL	A
296646-2	1	HOLDER & DRIVER, CARBON SEAL	
296650-1	1	GUIDE, INSTALLATION SEAL	
296652-1	1	HOLDER ASSY, TEST, RELIEF VALVE	
296673-1	1	GAGE, BRIDGE, MICROMETER	-
296683-1	1	INDICATOR SCALE, BUTTERFLY ANGLE (PART	B
296727-1	2	BOLT ALIGNMENT	-
296728-1	1	PULLER	-
296788-1	1	COMPUTER, ENGINE PERFORMANCE	B
296789-1	5	CALCULATOR EFR	
296797-1	4	GAGE STACKING	A
296798-1	1	CLAMP ASSY, ALIGNMENT	-
296811-1	1	WRENCH, SPLINED	A
296820-1	2	GAGE, CHECK RIVET HOLE	B
296862-1	1	ADAPTER	A
296883-2	1	DUMMY ROTOR SET	
296894-2	1	DRIVER, INSTALLATION, BEARING	-
296902-1	1	SPLINED WRENCH	A
296933-1	2	CABLE SET, SPECIAL PURPOSE	A
296960-1	2	DRIVER, SEAL	A
297164-1	2	ADAPTER	
297181-1	2	CABLE ASSY, SPECIAL PURPOSE	D
297184-1	2	METER, CURRENT, IGV TORQUE MOTOR	-
298032-1	2	PACKING GUIDE	
298035-1	1	HOIST ASSY, INST/REM TURBINE MODULE	C
298045-1	2	DRIVER	
298103-1	1	CABLE SET	B
298110-1	1	HOLDER & ADAPTER, TORQUE WRENCH	A
298118-1	0	HOLDER ASSY, BREATHER VALVE	A
298165-1	2	DRIVER, INSTALLATION, BEARING	

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
298177-1	6	ADAPTER, TORQUE WRENCH SPLINED	-
298235-3	1	ADAPTER SET, FUEL NOZZLE	
298269-2	4	MOUNT, VIBRATION PICK UP	A
298312-1	1	ADAPTER, PIN, WRENCH	-
298435-1	2	SIMULATOR, SPACER	C
298435-1	3	DUMMY SPACER	C
298435-2	4	DUMMY SPACER	C
298435-3	3	DUMMY SPACER	C
298836-2	1	TUBE	
298836-3	1	BAR	
298836-4	1	STRETCH FIXTURE-F-22 POWER SECTION	
3101018-6	1	BOLT SHOULDERED SPLINED	
345-503-9012	6	FUSE, CARTRIDGE	
3661093-1	1	ADAPTER SET, BUILD UP	A
3661792-1	7	PUNCH	
3791948-1	8	ADAPTER, VALVE TEST	-
3792284-1	1	ADAPTER ASSY.	-
3792284-2	1	ADAPTER ASSY.	-
3792284-3	1	ADAPTER ASSY.	-
5814960-2	2	STRETCH SHAFTS	
5826068-1	2	COVER	-
5836017-13	1	CARBON SEAL REMOVAL TOOL	
5836021-29	1	UNCRIMPING SHAFTS	
5836023-20	1	HOIST, LP TURBINE VERTICAL	
5836025-1	2	NUT, ADJUSTING	
5836128-1	2	WRENCH, TOWER SHAFT BOLT	
5836132-1	2	WRENCH	
5837006-1	1	COVER, HP BLEED PORT	-
5837033-2	3	SUPPORT ROT GRP	A
5837070-1	1	CART, ASSEMBLY, PLENUM	
5837074-10	1	PULLER (LESS CYLINDER)	
5837084-1	4	KIT, WRENCH, FUEL PUMP (NEED CASES)	
5837088-102	1	SHAFT	
5837124-1	5	MOUNT, VIBRATION PICKUP	-
5837143-1	2	SLING ASSY., LPT MODULE	-
5837161-1	4	ADAPTER, WATER WASH PORT	-
5837164-1	1	PROBE STATION 2.45	
5837825-1	0	KIT, BLEED PORT CAP	-
5838071-1	3	DRIVE ARM, BUILD STAND, ENGINE	B
5838204-1	1	BRACKET, ENGINE	-
5838444-1	1	FIXTURE ASSY., ENGINE LIFT	-
669412C1F015	7	CABLE AY	
831016-1	2	RETAINER, FAN BLADE	B
831025-1	1	MASK, BLADE, METAL SPRAY	A
831030-1	1	WRENCH, COMPRESSION SLEEVE	-
831034-1	1	FIXTURE, MICING	
831041-1	2	INSTALLATION & REMOVAL SEAL	-
831046-1	2	ADAPTER, TORQUE, IGV ACTUATOR	A
831086-1	1	COMPRESSOR BEARING	A
831177-1	1	PILOT, ALIGNMENT	-
831179-1	1	DRIVER, SPLINE	-
831180-1	1	PULLER, PROP-SHAFT FILLER	A

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
831189-1	1	VALVE, TEST	-
831360-1	2	FIXTURE, DRILLING, MAIN SUPPORT	A
831376-1	1	FIXTURE, DRILL GUIDE	B
831411-2	1	KIT, REMOVAL/INSTALLATION	G
831414-1	20	GUIDE FIN	
831417-1	1	ADAPTER, PROPSHAFT	-
831420-11	6	HELICAL SPUR GEAR NO ANODIZE	A
831486-1	1	#3 INNER RACE REMOVAL (PARTIAL)	-
831756-1	1	ARBOR, BALANCE (PARTIAL)	-
831762-1	3 sets	CLAMP ASSY, MANIFOLD	-
832000-1	2	HANDLE ASSY	-
832001-1	4	HANDLE ASSY, ANTI-ROTATION	A
832164-1	2	ENGINE SLING	G
832166-1	2	COVER, TRANSFER	
832327-1	1	SCREEN	A
832411-2	1	CABLE ASSY	A
832623-1	2	SHAFT, TORQUE, SPLINE	B
832662-1	2	TORQUE SHAFT, CARBON SEAL	E
832812-1	6	ITT HARNESS INSPECTION GAGE	A
833054-1	1	ADAPTER - Note: Cad Plated Hdwe - Change if for OVS	
833060-1	7	RESTRICTOR, FLUID FLOW	G
833060-10	7	RESTRICTOR, FLUID FLOW	D
833060-11	1	RESTRICTOR, FLUID FLOW	
833060-2	9	RESTRICTOR, FLUID FLOW	D
833060-4	5	RESTRICTOR, FLUID FLOW	D
833060-5	5	RESTRICTOR, FLUID FLOW	D
833060-6	4	RESTRICTOR, FLUID FLOW	D
833060-7	4	RESTRICTOR, FLUID FLOW	D
833060-8	8	RESTRICTOR, FLUID FLOW	D
833060-9	8	RESTRICTOR, FLUID FLOW	D
833094-200	5	NUT (PART OF 833094-1 FIXTURE)	B
833099-1	1	SUPPORT FIXTURE, TURBINE NOZZLE	
833175-1	1	SUPPORT BEARING CAR	A
833213-1	2	SHAFT	-
833254-1	2	TORQUE ADAPTER	
833258-1	2	NUT, SPECIAL	-
833426-1	1	HOLDER POWER	
833476-1	1	ADAPTER, VIBRATION TRANSDUCER	A
833491-1	1	DUCT, OIL COOLER	A
833493-1	1	ADAPTER SUPPORT	A
833804-1	2	WRENCH, SPANINER, VISE MOUNTED	
833805-1	2	WRENCH, SPANINER	
833877-4A	9	ADAPTER, FLARELESS MS TO FLARED AN	
833924-1	1	FIXTURE, LIFT ENGINE	
833978-3	1	ADAPTER, BEARING REMOVAL	C
833992-1	1	PULLER FAN ROTOR	C
834040-1	1	ADAPTER, SEAL REMOVAL	-
834117-1	6	MOUNT ASSY, LH	B
834134-1	2	MOUNT, VIBRATION ACCELEROMETER	A
834154-1	1	PLATE, SEAL REMOVAL	
834169-1	2	ADAPTER, SPLINE	-
834172-1	2	INSTALLER	-

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

8/4/2010

PART NUMBER	QTY	DESCRIPTION	REV
834174-1	1	DUMMY SHAFT	
834177-1	1	BRIDGE, MICROMETER	A
834190-1	2	COMPRESSOR, SPRING	
834193-1	1	ARBOR, EXPANSION	
834209-1	2	WRENCH, SPECIAL	
834238-1	1	COMPRESSOR PISTON RING	-
834263-2	1	TIE BOLT ASSY, ARBOR	
834268-1	1	WRENCH, SPECIAL	-
834355-1	7	GUIDE	A
834384-1	2	FIXTURE ASSY, HOLDING, VALVE	
834415-2	3	SHAFT ADAPTER	-
834415-7	2	ADAPTER, SPLINE	
834432-1	1	SIMULATOR, TORQUE MOTOR	A
834543-1	1	SPACE	
834563-1	8 SETS	COMPRESSOR, RING	
834620-1	2	WRENCH	-
834621-1	1	COUPLING, DRIVE SHAFT	
834622-1	1	ADAPTER, COUPLING, DRIVE	
834629-1	2	FIXTURE ASSY, DUMMY ROTOR (PARTIAL)	-
834630-1	2	FIXTURE, ALIGNMENT, ASSEMBLY (PARTIAL)	
834666-1	2	ADAPTER, TORQUE	-
834701-1	2	BEARING DRIVER	A
834702-1	1	DRIVER	A
834707-1	1	DRIVER	A
834713-1	1	SIMULATOR	A
834720-2	2	STRETCH SHAFT	D
834720-4	3	SHAFT ADAPTER	D
834726-1	3	INSTALL/REMOVE	A
834740-12	1	NUT, STRETCH SHAFT	C
834740-5	7	NUT, STRETCH SHAFT	C
834740-6	5	NUT, STRETCH SHAFT	C
834740-7	3	NUT, STRETCH SHAFT	C
834740-8	3	NUT, STRETCH SHAFT	C
834740-9	3	NUT, STRETCH SHAFT	C
834743-1	1	PULLER ASSEMBLY	B
834759-7	1	ADAPTER, STEP	
834759-9	1	ADAPTER, STEP	
834808-1	1	DUPLEX BEARING PULLER	B
834809-1	2	ALIGNMENT PIN	B
834812-1	1	ADAPTER, WHEEL REMOVAL	A
834819-1	1	DRIVER, BEARING	B
834834-1	3	ADAPTER, TORQUE	A
834887-1	2	IGV GAUGE SET	A
834889-4	1	SHAFT	
834909-1	1	SHAFT, QUILL	A
834926-1	2	SIMULATOR, ROLLER BEARING	A
835082-1	4	SHAFT ALIGNMENT	A
835112-1	2	GUIDE, O RING	-
835160-1	1	STRIKING TOOL	A
835333-1	1	HOLDER, BENCH ASSY	-
835358-1	4	BULLET, ASSEMBLY	
835393-1	1	O RING GUIDE	-

Contact: Becky Henning
 Phone: 989-845-3880
 Fax: 989-845-2073

8/4/2010

JETOOL
MASTER STOCK LIST
 (Sold on first-come, first-serve basis)

PART NUMBER	QTY	DESCRIPTION	REV
835530-1	1	DRIVER ASSY	B
835584-1	1	TIE BOLT, ARBOR	-
835676-1	1	FIXTURE ASSY, RIVETING TURBINE WHEEL	A
835691-1	3	ALIGNMENT PIN	-
835761-1	1	SPACER, SPRING	-
835764-1	5	ANVIL, RIVETING	-
835766-1	2	ANVIL, RIVETING	-
835767-1	2	DRIVER, RIVETING	-
835815-1	2	COMPRESSOR, RING	A
835823-1	1	ARBOR, SEAL INSTALLATION	A
835841-1	1	ARBOR, BEARING PRESS	-
835851-1	1	ARBOR, BEARING PRESS	-
835886-1	4	SHAFT, ALIGNMENT	
835916-1	1	WASHER, ALIGNMENT TOOL	-
855162-13	1	SETSCREW ORIFICE	
899598	1	DYNAMIC SEAL TOOL	-
899601	1	PULLER	
901747-1	1	ADAPTER	
905956-1-1	4	TRIM BALANCE DR	
916268-1-1	1	ARBOR SET	
918352-1-1	1	HARNESS ADAPTER	
932363-1	1	TUBE ASSY EXHAUST	
G278214	2SETS	AIRFLOW MASTER (PARTIAL)	
LTCT7690-01	1	WRENCH	-
LTCT7690-04	1	WRENCH	-
MSC446-1	1	COLLET	
P47H-07-198	1	COUPLING	